


ZOTAC Extreme GTX1080/1070 GPU Water Block

BS-ZOZ1080-PA




Remove the red position screw

①



Remove the radiator and screw the screws in place

②




Original backplane removal , Clean up and reapply GPU core thermal grease ③




In the water block floor with good thermal grease

④



Attention to red position screw for installation drawing

⑤



installation is complete

⑥