


COLORFUL GTX1050Ti/1050 GPU Water Block

BS-COG1050T-PA



Remove the red position screw

①



Remove the original radiator

②



Clean up and reapply GPU core thermal grease

③



In the water block floor with good thermal grease

④

